

# Product data sheet

Centre plate with knob for rotary switch




---

**Reference number**


---

GCR 1941

**Centre plate with knob**

for rotary switch ref.-no.: 1101-4, 1101-20  
 for timer switch ref.-no.: 11015, 11120-20  
 for rotary blind switch ref.-no.: 1234.10, 1234.20

also for volume control WHD type: LST..JU UP and LR..JU UP  
 and for program selection WHD type: PRO 3 JU..

**Metal versions**

**Colour:**  
 chrome

**Material:**  
 metal, chromium-plated

---

**P** Colour printing possible